




























































































| Original  |              | Replacement   |       | Original  |            | Replacement   |        |
|---|--------------|---|-------|---|------------|---|--------|
|    | Power        |    | Power |    | Audio      |    | Dual   |
|    | Open/Close   |    | Eject |    | TRK Up     |    | Vol +  |
|    | 1            |    | 1     |    | TRK Down   |    | Vol -  |
|    | 2            |    | 2     |    | Prog Up    |    | Ch +   |
|    | 3            |    | 3     |    | Prog Down  |    | Ch -   |
|    | 4/<< Shuttle |    | 4     |    | F.ADV/Step |    | Yellow |
|    | 5            |    | 5     |    | I<<        |    | I<<    |
|    | 6/Shuttle >> |    | 6     |    | <<         |    | <<     |
|    | 7            |    | 7     |    | Stop       |    | Stop   |
|    | 8            |    | 8     |    | Play       |    | Play   |
|    | 9            |    | 9     |    | Pause      |    | Pause  |
|   | 0            |   | 0     |   | >>I        |   | >>I    |
|  | Clear        |  | Exit  |  | >>         |  | >>     |
|  | Tv/VCR       |  | TV/R  |  | Menu       |  | Menu   |
|  | DVD          |  | Media |  | Subtitle   |  | Subt   |
|  | VCR          |  | Smart |  | Info       |  | Info   |
|  | Input Sel    |  | AV    |  | Return     |  | Back   |





| Original  |             | Replacement   |            | Original | Replacement |
|---|-------------|---|------------|----------|-------------|
|    | Up          |    | Up         |          |             |
|    | Left        |    | Left       |          |             |
|    | OK          |    | Ok         |          |             |
|    | Right       |    | Right      |          |             |
|    | Down        |    | Down       |          |             |
|    | Rec         |    | Rec        |          |             |
|    | Speed       |    | Red        |          |             |
|    | EZ View     |    | 3D         |          |             |
|    | Disc Menu   |    | D. Menu    |          |             |
|    | IPC/Angle   |    | Green      |          |             |
|  | Repeat/Mode |  | Text       |          |             |
|  | Search/Mark |  | Format     |          |             |
|  | Timer       |  | Shift + AV |          |             |
|   |             |   |            |          |             |
|   |             |   |            |          |             |
|   |             |   |            |          |             |
|   |             |   |            |          |             |
|   |             |   |            |          |             |

