
































































































Original		Replacement		Original		Replacement	
	Power		Power		CH+		Ch +
	Mute		Mute		CH-		Ch -
	1		1		Up		Up
	2		2		Down		Down
	3		3		Right		Right
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Exit		Exit
	7		7		Text		Text
	8		8		Menu		Menu
	9		9		Aspect		3D
	0		0		Size		Format
	Recall		Guide		Sleep		Sleep
	Source		Pre Ch		Media		Media
	Vol+		AV		Reveal		Options
	Vol-		Vol +		Info		Info
	Vol-		Vol -		Tv/Radio		TV/R





Original	Replacement	Original	Replacement
 I/II/Audio	 Dual	 Repeat	 Shift + Text
 Subtitle	 Subt		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Rec	 Rec		
 I<<	 I<<		
 >>I/Index	 >>I		
 <</Subpage	 <<		
 >>/Hold	 >>		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 PIC Mode	 Shift + Format		
 S.Mode	 Shift + Dual		
 Rec Menu	 Shift + Rec		

Original	Replacement	Original	Replacement
 Repeat	 Shift + Text		

