

































































































Original		Replacement		Original		Replacement	
	Power		Power		Guide		Guide
	Source		AV		Tools		Options
	1		1		Smart Hub		Smart
	2		2		Info		Info
	3		3		Return		Back
	4		4		Exit		Exit
	5		5		Enter		Ok
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		Red		Red
	TTX/MIX		Text		Green		Green
	PRE-CH		Pre Ch		Yellow		Yellow
	Mute		Mute		Blue		Blue
	CH List		List		Social Tv		Media
	Menu		Menu		3D		3D





	Original	Replacement		Original	Replacement
	P.Size	 Format			
	AD/Subt.	 Subt			
	Search	 TV/R			
	E-Manual	 D. Menu			
	Play	 Play			
	Rec	 Rec			
	Stop	 Stop			
	Pause	 Pause			
	<</ <<	 <<			
	>>/>>	 >>			
	Vol+	 Vol +			
	Vol-	 Vol -			
	P+	 Ch +			
	P-	 Ch -			

