







































































Original		Replacement		Original		Replacement	
	Power		Power		FAV/Mark		Pre Ch
	Energy/Saving		3D		Ratio		Format
	AV Mode		Media		Vol+		Vol +
	Input		AV		Vol-		Vol -
	Tv/Radio		TV/R		Mute		Mute
	1		1		PR+		Ch +
	2		2		PR-		Ch -
	3		3		Menu		Menu
	4		4		Guide		Guide
	5		5		Q.Menu		D. Menu
	6		6		Back		Back
	7		7		Info		Info
	8		8		Exit		Exit
	9		9		Up		Up
	0		0		Down		Down
	List		List		Right		Right
	Q.View		Sleep		Left		Left





Original		Replacement		Original		Replacement	
	OK		Ok				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text		Text				
	T.Opt		Options				
	Subtitle		Subt				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	<<		<<				
	>>		>>				
	Simplink		Smart				

