







































































Original	Replacement	Original	Replacement
 Power	 Power	 CH+	 Ch +
 Source	 AV	 CH-	 Ch -
 Sleep	 Sleep	 Down	 Down
 Mute	 Mute	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Vol-	 Vol -
 3	 3	 Vol+	 Vol +
 4	 4	 Enter	 Ok
 5	 5	 Red	 Red
 6	 6	 Green	 Green
 7	 7	 Yellow	 Yellow
 8	 8	 Blue	 Blue
 9	 9	 Info	 Info
 0	 0	 EPG	 Guide
 -/--	 Shift + Guide	 Menu	 Menu
 Recall	 Pre Ch	 Nicam	 Media
 Up	 Up	 FAV+	 >>





Original		Replacement		Original		Replacement	
	FAV-		<<				
	TXT		Text				
	Edit/Group		Options				
	Index		Back				
	Lang/Audio		Dual				
	TV/Radio		TV/R				
	Subtitle		Subt				
	Subpage	+	Shift + Subt				
	Size		Format				
	Hold		3D				
	Still		Exit				
	P.Mode	+	Shift + Format				
	S.Mode	+	Shift + Dual				

