







































































Original		Replacement		Original		Replacement	
	Power		Power		4		4
	OK		Ok		5		5
	Up		Up		6		6
	Down		Down		7		7
	Right		Right		8		8
	Left		Left		9		9
	Menu		Menu		0		0
	Mute		Mute		P<P		Pre Ch
	> <		Smart		[i+]		Info
	[≡]		Text		[112]		Options
	P+		Ch +		[-O-]/Active Control		Media
	P-		Ch -		[<>]		Format
	Vol+		Vol +		Source		AV
	Vol-		Vol -		(O)		TV/R
	1		1		Red		Red
	2		2		Green/Timer		Green
	3		3		Yellow/[ ]		Yellow









































































Original	Replacement	Original	Replacement
	Blue/[...]		Blue
	Rec		Rec
	<<		<<
	Stop		Stop
	Play		Play
	>>		>>
	[[[]]]		Guide
	Power AMP		Shift + Power
	[≡] AMP		Shift + Text
	[[[]]] AMP		Shift + Guide
	OK AMP		Shift + Ok
	Up AMP		Shift + Up
	Down AMP		Shift + Down
	Right AMP		Shift + Right
	Left AMP		Shift + Left
	Menu AMP		Shift + Menu
	P+ AMP		Shift + Ch +
	P- AMP		Shift + Ch -
	Mute AMP		Shift + Mute
	Vol+ AMP		Shift + Vol +
	Vol- AMP		Shift + Vol -
	1 AMP		Shift + 1
	2 AMP		Shift + 2
	3 AMP		Shift + 3
	4 AMP		Shift + 4
	5 AMP		Shift + 5
	6 AMP		Shift + 6
	7 AMP		Shift + 7
	8 AMP		Shift + 8
	9 AMP		Shift + 9
	0 AMP		Shift + 0
	P<P AMP		Shift + Pre Ch
	>> AMP		Shift + >>
	<< AMP		Shift + <<











































































Original		Replacement		Original		Replacement	
	Power		Power		P-		Ch -
	Source		AV		Vol+		Vol +
	>>		>>		Vol-		Vol -
	<<		<<		1		1
	Stop		Stop		2		2
	Play		Play		3		3
	[[[]]]		Guide		4		4
	[[]]		Text		5		5
	OK		Ok		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0
	> <		Smart		[i+]		Info
	Menu		Menu		P<P		Pre Ch
	Mute		Mute		[12]		Options
	P+		Ch +		[-O]/Active Control		Media







































































Original		Replacement		Original		Replacement	
	Power		Power		Mute		Mute
	Source		AV		P+		Ch +
	(O		TV/R		P-		Ch -
	Red		Red		Vol+		Vol +
	Green/Timer		Green		Vol-		Vol -
	Yellow/[ ]		Yellow		> <		Smart
	Blue/[...]		Blue		Menu		Menu
	>>		>>		1		1
	Rec		Rec		2		2
	<<		<<		3		3
	Stop		Stop		4		4
	Play		Play		5		5
	OK		Ok		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0































































Original	Replacement	Original	Replacement
	[i+]  Info		> < VCR  Shift + Smart
	P<P  Pre Ch		Menu VCR  Shift + Menu
	[1 2]  Options		P+ VCR  Shift + Ch +
	[-O-]/Active Control  Media		P- VCR  Shift + Ch -
	[<>]  Format		1 VCR  Shift + 1
	Power VCR  Shift + Power		2 VCR  Shift + 2
	Source VCR  Shift + AV		3 VCR  Shift + 3
	Rec VCR  3D		4 VCR  Shift + 4
	>> VCR  Shift + >>		5 VCR  Shift + 5
	<< VCR  Shift + <<		6 VCR  Shift + 6
	Stop VCR  Shift + Stop		7 VCR  Shift + 7
	Play VCR  Shift + Play		8 VCR  Shift + 8
	OK VCR  Shift + Ok		9 VCR  Shift + 9
	Up VCR  Shift + Up		0 VCR  Shift + 0
	Down VCR  Shift + Down		[i+] VCR  Shift + Info
	Right VCR  Shift + Right		P<P VCR  Shift + Pre Ch
	Left VCR  Shift + Left		





Original		Replacement		Original		Replacement	
	Power		Power		2		2
	>>		>>		3		3
	<<		<<		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	[[I]]		Guide		7		7
	Up		Up		8		8
	Down		Down		9		9
	Right		Right		0		0
	Left		Left		[i+]		Info
	>I<		Smart		P<P		Pre Ch
	Mute		Mute				
	Vol+		Vol +				
	Vol-		Vol -				
	P+		Ch +				
	P-		Ch -				
	1		1				

