









Original		Replacement		Original		Replacement	
	Power		Power		←PR		Back
	Mute		Mute		FAV		Pre Ch
	1		1		Up		Up
	2		2		PR+		Ch +
	3		3		PR-		Ch -
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		Red/Find		Red
	0		0		Green/Zoom		Green
	Tv/Radio		TV/R		Yellow		Yellow
	EPG		Guide		Text		Text
	Menu		Menu		Blue		Blue
	Exit		Exit		Audio L/R		Dual
	OK/List		Ok		Info		Info





Original		Replacement		Original		Replacement	
	Tv/AV		AV				
	Sleep		Sleep				
	[+]		Options				
	Record		Rec				
	Play		Play				
	Stop		Stop				
	Shift		Media				
	<< Fast		<<				
	Fast >>		>>				
	< Slow		I<<				
	Slow >		>>I				
	Pause		Pause				
	↑/Page+		3D				
	↓/Page-		Format				

