





































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 Guia	 Guide
 ver Tv	 TV/R
 Favoritos	 Pre Ch
 Menu	 Menu

Original	Replacement
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Atrás	 Back
 Salir	 Exit
 abc/Borrar	 Options
 VOD/Videoclub	 Smart
 Familiar	 Subt
 Multimedia	 Media
 Vol+	 Vol +
 Vol-	 Vol -
 Prog+	 Ch +
 Prog-	 Ch -
 X/Zoom	 3D
 Rec	 Rec
 Play	 Play





Original	Replacement	Original	Replacement
 Pause	 Pause		
 Stop	 Stop		
 >>	 >>		
 <<	 <<		
 I<<	 I<<		
 >>I	 >>I		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 OK	 Ok		
 Q..	 Dual		

