



Original		Replacement		Original		Replacement	
	Power		Power		TTX		Text
	Angle		Red		Audio		Dual
	Av Out/Av In		AV		PBC/Scan		Options
	DVB/DVD		Smart		Title		Info
	1		1		Up		Up
	2		2		PR+		Ch +
	3		3		Stop		Stop
	4		4		Play		Play
	5		5		Pause		Pause
	6		6		Left		Left
	7		7		Vol-		Vol -
	8		8		OK		Ok
	9		9		Right		Right
	0		0		Vol+		Vol +
	10+		Pre Ch		Mode		Back
	Mute		Mute		Setup/Exit		Exit
	Subtitle		Subt		Down		Down





Original	Replacement	Original	Replacement
	PR-		Ch -
	Zoom		Eject
	Menu		Menu
	Repeat		Shift + Text
	Tv/Radio/A-B		TV/R
	I<<		I<<
	>>I		>>I
	Pro/EPG		Guide
	Display		Shift + Info
	<</FAV		<<
	>>/PG-TV		>>

