





































































































	Original	Replacement		Original	Replacement
	Power		Power		Size/Fav List
	Mute		Mute		Subpage/Play List
	OK		Ok		Red/Record
	Up		Up		Green
	Down		Down		Yellow
	Right		Right		Blue
	Left		Left		Energy
	Menu		Menu		Picture
	Input		AV		Sound
	Exit		Exit		Audio
	Info		Info		[...]/Subtitle
	Vol+		Vol +		16:9/4:3
	Vol-		Vol -		Sleep
	CH+		Ch +		TTX
	CH-		Ch -		Recall/Repeat
	Hold/EPG		Options		1
	Index/CH.List		List		2
					Format
					Eject
					Red
					Green
					Yellow
					Blue
					Guide
					Shift + Format
					Dual
					3D
					Subt
					D. Menu
					Sleep
					Text
					Back
					1
					2





	Original	Replacement		Original	Replacement
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		
	8		8		
	9		9		
	0		0		
	Play		Play		
	Stop		Stop		
	<</REV		<<		
	>>/FF		>>		
	Pause		Pause		
	→		TV/R		
	<<		<<		
	>>		>>		

