







































































Original		Replacement		Original		Replacement	
	Power		Power		Menu		Menu
	Open/Close		Eject		Prog/EPG		Sleep
	1		1		Display		Info
	2		2		Goto		Pre Ch
	3		3		PBC		Options
	4		4		Setup		D. Menu
	5		5		Return		Back
	6		6		Source		AV
	7		7		Tv/Radio		TV/R
	8		8		Play		Play
	9		9		Stop		Stop
	0		0		Pause		Pause
	10+		Guide		<</Rev		<<
	Vol+		Vol +		>>/Fwd		>>
	Vol-		Vol -		I<</Prev		I<<
	Mute		Mute		>>I/Next		>>I
	Title/TTX		Text		Up		Up





	Original	Replacement	Original	Replacement
	Down			
	Right/Fav+			
	Left/Fav-			
	Enter			
	3D			
	Subtitle			
	Zoom			
	Mode			
	Digest			
	Language			
	L/R			
	P/N			
	Repeat			
	A-B			
	Angle			
	Slow			

