







































































Original	Replacement	Original	Replacement
 Power	 Power	 PR-	 Ch -
 Source	 AV	 Mute	 Mute
 1	 1	 Ch.List	 List
 2	 2	 Media.P	 Media
 3	 3	 Menu	 Menu
 4	 4	 Guide	 Guide
 5	 5	 Tools	 Options
 6	 6	 Info	 Info
 7	 7	 Return	 Back
 8	 8	 Exit	 Exit
 9	 9	 Enter	 Ok
 0	 0	 Up	 Up
 TTX/MIX	 Text	 Down	 Down
 PRE-CH	 Pre Ch	 Right	 Right
 Vol+	 Vol +	 Left	 Left
 Vol-	 Vol -	 Red	 Red
 PR+	 Ch +	 Green	 Green





Original		Replacement		Original	Replacement
	Yellow		Yellow		
	Blue		Blue		
	P.Mode	 + 	Shift + Format		
	S.Mode	 + 	Shift + Dual		
	Dual I/II		Dual		
	AD	 + 	Shift + Subt		
	P.Size		Format		
	Subt.		Subt		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

