


































































	Original	Replacement		Original	Replacement
	Power		Power		List
	Tv/Radio		TV/R		Settings
	3D		3D		Q.View
	Guide		Guide		Q.Menu/3D
	Info		Info		Up
	Ratio		Format		Mute
	Input		AV		Down
	1		1		Right
	2		2		Left
	3		3		Ok
	4		4		Back
	5		5		FAV
	6		6		FAV
	7		7		Exit
	8		8		PIP/AD
	9		9		Vol+
	0		0		Vol-
					List
					Shift + Options
					Pre Ch
					Media
					Mute
					Back
					Smart
					Shift + Pre Ch
					Exit
					Dual
					Vol +
					Vol -





Original		Replacement		Original		Replacement	
	P+		Ch +				
	P-		Ch -				
	Red		Red				
	Green		Green				
	Yellow/*-		Yellow				
	Blue/*+		Blue				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	Subtitle		Subt				
	<<		<<				
	>>		>>				
	Text		Text				
	T.Opt		Options				

