





































































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Up		Up
	3		3		Down		Down
	4		4		Left		Left
	5		5		Right		Right
	6		6		Ok		Ok
	7		7		PgUp		>>
	8		8		PgDn		<<
	9		9		Tv/Radio		TV/R
	0		0		Info		Info
	Mute		Mute		Audio		Dual
	Recall		Back		FAV		Pre Ch
	Menu		Menu		Sub-T		Subt
	Exit		Exit		TTX		Text
	CH+		Ch +		EPG		Guide
	CH-		Ch -		Play		Play



