










































































Original	Replacement	Original	Replacement
	Power		Power
	Exit		Exit
	Source		AV
	Tv/Radio		TV/R
	Mute		Mute
	PR List		List
	FAV		Pre Ch
	Audio	 + 	Shift + Dual
	Info		Info
	EPG		Guide
	Subtitle		Subt
	Teletext		Text
	Guide	 + 	Shift + Guide
	Music		Green
	S.Show		Red
	Zoom		Eject
	Repeat	 + 	Shift + Text
			<<
			>>
			l<<
			>>l
	Play		Play
	Pause		Pause
	Stop		Stop
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	P.ADJ		3D



