






| Original | Replacement |
|--|---|
|  Power |  Power |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  PopUp Menu/Disc Menu |  D.Menu / Top |
|  Home |  Menu / Home |
|  Top Menu |  Picture / Format |
|  Up |  Up |
|  Left |  Left |
|  OK |  OK |
|  Right |  Right |
|  Down |  Down |
|  Back |  Back / Return |
|  :≡ |  Smart / List |
|  :≡ |  Setup / OPT / |
|  Play |  Play / Slow |

| Original | Replacement |
|--|---|
|  Pause |  Pause / Step / Freeze |
|  I< |  I<< / Preset- |
|  Stop |  Stop / Hold |
|  Eject |  Eject / Surround |
|  >I |  >>I / Preset+ |
|  << |  << / Tune- |
|  >> |  >> / Tune+ |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Subtitle |  Subtitle / EQ |



