











































































































































Original		Replacement		Original		Replacement	
	Power		Power		Mute Tv		Mute / Dimmer
	Open/Close		Eject / Surround		Vol- Tv		Vol-
	Power Tv		Shift + Power		<<		<< / Tune-
	AV Tv		AV / Input / RDS		>>		>> / Tune+
	1		1		I<<		I<< / Preset-
	2		2		>>I		>>I / Preset+
	3		3		Pause/Step		Pause / Step / Freeze
	PR+ Tv		CH+ / Page+		Play		Play / Slow
	4		4		Stop		Stop / Hold
	5		5		Display		Display / Media
	6		6		Up		Up
	PR- Tv		CH- / Page-		Setup		Setup / OPT /
	7		7		Left		Left
	8		8		Enter		OK
	9		9		Right		Right
	Vol+ Tv		Vol+		Disc Menu		D.Menu / Top
	0		0		Down		Down





Original	Replacement
 Power	 Power
 Eject	 Eject / Surround
 AV	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Tv/VCR	 TV/Radio /
 0	 0
 <<	 << / Tune-
 >>	 >> / Tune+
 Pause/Step	 Pause / Step / Freeze

Original	Replacement
 Play	 Play / Slow
 Stop	 Stop / Hold
 CLK/CNT	 Display / Media
 Up	 Up
 PR/TRK+	 CH+ / Page+
 i	 Info / Angle
 Left	 Left
 Enter	 OK
 Right	 Right
 PR/TRK-	 CH- / Page-
 Down	 Down
 O)))/Audio	 Audio / Lang I/II
 Rec/ITR	 Rec / Rec Mode
 Lock	 Back / Return
 Search	 Red / Netflix / Search
 Clear	 Exit / Cancel / Clear
 Repeat	 Green / APP / Repeat



