







































































Original		Replacement		Original		Replacement	
	Power		Power		*		Menu
	Mute		Mute		P+		Ch +
	1		1		P-		Ch -
	2		2		Home		Smart
	3		3		≡		Options
	4		4		←		Back
	5		5		Source		AV
	6		6		Up		Up
	7		7		Down		Down
	8		8		Right		Right
	9		9		Left		Left
	0		0		OK		Ok
	T		TV/R		Exit		Exit
	List		List		Text		Text
	Vol+		Vol +		O)/Lang		Dual
	Vol-		Vol -		Guide		Guide
	[i]		Info		Subt.		Subt



