



Original	Replacement	Original	Replacement
	Power		Power
	Coax		Red
	Play		Play
	Pause		Pause
	Optical		Green
	AUX		Yellow
	USB		Blue
	I<		I<<
	>I		>>I
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Treble+		Ch +
	Treble-		Ch -
	Bass+		Up
	Bass-		Down
	Audio Sync -		Left
	Audio Sync +		Right
	Surround Off		Format
	Surround On		3D
	Sound		Dual
	DIM		Media
	Night		Smart
	Bluetooth		Guide
	HDMI ARC		Pre Ch

