
















































Original	Replacement	Original	Replacement
	Power		Power
	Back		Back
	Home		Smart
	TV		TV/R
	Micro		Dual
	Up		Up
	Down		Down
	Left		Left
	Right		Right
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	3D		3D
	123/Input		Media
	Mute		Mute
	Mouse Up		>>
	Mouse Down		<<
	OK		Ok

