



| Original | Replacement | Original | Replacement |
|--|--|---|--|
|  Power |  Power |  Source |  AV |
|  TV |  TV/R |  P+ |  Ch + |
|  1 |  1 |  P- |  Ch - |
|  2 |  2 |  CH List |  List |
|  3 |  3 |  Menu |  Menu |
|  4 |  4 |  FAV CH |  Shift + Pre Ch |
|  5 |  5 |  Tools |  Options |
|  6 |  6 |  Return |  Back |
|  7 |  7 |  Info |  Info |
|  8 |  8 |  Exit |  Exit |
|  9 |  9 |  Up |  Up |
|  0 |  0 |  Down |  Down |
|  Enter |  Smart |  Right |  Right |
|  PRE-CH |  Pre Ch |  Left |  Left |
|  Vol+ |  Vol + |  OK |  Ok |
|  Vol- |  Vol - |  Red |  Red |
|  Mute |  Mute |  Green |  Green |





| Original | | Replacement | | Original | | Replacement | |
|---|---------|---|--------|----------|--|-------------|--|
|  | Yellow |  | Yellow | | | | |
|  | Blue |  | Blue | | | | |
|  | TTX/Mix |  | Text | | | | |
|  | Media.P |  | Media | | | | |
|  | P.Size |  | Format | | | | |
|  | Dual |  | Dual | | | | |
|  | Guide |  | Guide | | | | |
|  | Subt. |  | Subt | | | | |
|  | << |  | << | | | | |
|  | Pause |  | Pause | | | | |
|  | >> |  | >> | | | | |
|  | Rec |  | Rec | | | | |
|  | Play |  | Play | | | | |
|  | Stop |  | Stop | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

