



Original	Replacement
 Power	 Power
 Red / ↑	 Red / Netflix / Search
 Green / ↓	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 M	 Menu / Home
 Return	 Back / Return
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Source	 AV / Input / RDS
 Presets	 D.Menu / Top
 Info	 Info / Angle
 EPG	 Guide / EPG / -/--
 Vol+	 Vol+

Original	Replacement
 Mute	 Mute / Dimmer
 P+	 CH+ / Page+
 Vol-	 Vol-
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 FAV	 Shift + Fav / Marker / PC
 0	 0
 Recall	 Fav / Marker / PC
 Screen	 Picture / Format





Original		Replacement		Original		Replacement	
LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II				
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
(O)	(O)	MEDIA DISPLAY	Display / Media				
O/World	O/World	LIST SMART	Smart / List				
[≡x]	[≡x]	PROGRAM TV/RADIO	TV/Radio /				
[≡]	[≡]	GOTO TEXT	Text / Goto				

