





















































	Original	Replacement		Original	Replacement
	Power		Power		I/II
	Input TV		TV/R		Sleep
	Input		AV		Up
	ARC		Media		Down
	*+		Shift + Right		Right
	-*		Shift + Left		Left
	Text		Text		OK
	PIP		3D		Vol +
	Size		Format		Vol -
	Position		Options		Mute
	Red/PIP PR-		Red		PR+
	Green/PIP PR+		Green		PR-
	Yellow/Swap		Yellow		Q.View
	Blue/PIP Input		Blue		1
	Exit		Exit		2
	List		List		3
	Menu		Menu		4










































Original		Replacement		Original		Replacement	
	Power		Power		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	Pause		Pause		7		7
	I<<		I<<		8		8
	<<		<<		9		9
	>>		>>		0		0
	>>I		>>I				
	Menu		Menu				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	OK		Ok				
	1		1				
	2		2				
	3		3				





	Original	Replacement		Original	Replacement
	Power		Power		8
	Input		AV		9
	Stop		Stop		0
	Play		Play		
	Pause		Pause		
	Rec		Rec		
	<<		<<		
	>>		>>		
	PR+		Ch +		
	PR-		Ch -		
	1		1		
	2		2		
	3		3		
	4		4		
	5		5		
	6		6		
	7		7		

