












































































Original		Replacement		Original		Replacement	
	Power		Power		CH+		Ch +
	Display		Info		CH-		Ch -
	Guide		Guide		1		1
	Source		AV		2		2
	Wide		Format		3		3
	MPX		Back		4		4
	Menu		Menu		5		5
	Back/Cancel		Exit		6		6
	Mute		Mute		7		7
	FAV		Pre Ch		8		8
	OK		Ok		9		9
	Up		Up		0		0
	Down		Down		Teletext		Text
	Right		Right		Subtitle		Subt
	Left		Left		Red		Red
	Vol+		Vol +		Green		Green
	Vol-		Vol -		Yellow		Yellow





Original	Replacement	Original	Replacement
	Blue		Blue
	Size/Stop		Stop
	Hold/Play		Play
	Pause		Pause
	Reveal/>>I		>>I
	Index/I<<<		I<<<
	Rec		Rec

