







































































Original	Replacement	Original	Replacement
 Power	 Power	 EPG	 Guide
 Mute	 Mute	 Sat	 Smart
 1	 1	 Exit	 Exit
 2	 2	 Up	 Up
 3	 3	 Prog +	 Ch +
 4	 4	 Down	 Down
 5	 5	 Prog -	 Ch -
 6	 6	 Right	 Right
 7	 7	 Vol +	 Vol +
 8	 8	 Left	 Left
 9	 9	 Vol -	 Vol -
 0	 0	 Ok	 Ok
 Pause	 Pause	 TV / Radio	 TV/R
 Recall	 Back	 Zoom	 Eject
 Fav	 Pre Ch	 Page -	 I<<
 Menu	 Menu	 Page -	 <<
 i	 Info	 PIP	 List





	Original	Replacement	Original	Replacement
	F1	 Options		
	Page +	 >>		
	Page +	 >>		
	UHF	 Format		
	P/N	 3D		
	TV/SAT	 Media		
	Subtitles	 Subt		
	Red / Audio	 Red		
	Audio	 Dual		
	Green / Mosaic	 Green		
	Yellow / Clock	 Yellow		
	Text	 Text		
	Blue / Text	 Blue		

