





































Original	Replacement
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV	 TV/R
 RGB	 List
 Vol+	 Vol +
 Vol-	 Vol -
 CH+	 Ch +

Original	Replacement
 CH-	 Ch -
 Mute	 Mute
 In Stop	 D. Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right/time Shift	 Right
 Left/Time Shift	 Left
 Menu	 Menu
 Exit	 Exit
 In Start	 Eject
 ADJ	 Options
 XStudio	 Dual
 Text	 Text
 Check-P	 Shift + Left
 Check-S	 Shift + Right
 PSM	 Pre Ch





Original	Replacement
 PIP	 3D
 CAP	 Info
 MPX	 Sleep
 SSM	 Subt
 ARC	 Format
 Red/Info	 Red
 Green/Still	 Green
 Yellow/HDMI-HO	 Yellow
 Blue/USB-HOT	 Blue
 Eye	 Back
 B-Tooth	 Smart
 Simplink / PIP PR-	 Shift + Ch -
 PIP PR +	 Shift + Ch +
 Tilt/PIP Input	 Shift + AV
 Play	 Play
 Pause/Swap	 Pause
 >>I	 >>I

Original	Replacement
 I<<	 I<<
 P-Only	 Guide
 AV1	 Shift + 1
 AV2	 Shift + 2
 AV3	 Shift + 3
 COMP1	 Shift + 4
 COMP2	 Shift + 5
 HDMI1	 Shift + 6
 HDMI2	 Shift + 7
 HDMI3	 Shift + 8
 HDMI4/DVI	 Shift + 9

