

































































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	Recall		Back
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	P.Mode		Shift + Format
	S.Mode		Shift + Dual
	Aspect		3D
	TXT		Text
	Audio		Dual
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	PR+		Ch +
	PR-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Display		Info





	Original	Replacement		Original	Replacement
	Sleep	 Sleep		>>/PgDn	 >>
	Rec	 Rec		<</PgUp	 <<
	Menu	 Menu		Stop	 Stop
	Hold	 Options		Play	 Play
	MIX	 Media		Pause	 Pause
	Subpg.	 +  Shift + Subt		Repeat	 +  Shift + Text
	Index	 Exit			
	Size	 Format			
	Reveal	 Smart			
	DTV/Radio	 TV/R			
	EPG	 Guide			
	FAV	 Pre Ch			
	List	 List			
	PVR Menu	 D. Menu			
	DTV Subt.	 Subt			
	I<<	 I<<			
	>>I	 >>I			

