













































































































Original		Replacement		Original		Replacement	
	Power On		Power		Memory		Blue
	Power Off		Shift + Power		Search		TV/R
	1/BD		1		Input Mode		AV
	2/(SAT/CBL)		2		CH+		Ch +
	3/(DOCK)		3		CH-		Ch -
	Status		4		Sleep		Sleep
	BD		5		Audio Delay		Smart
	Tuner		6		Mute		Mute
	DVD		7		Vol+		Vol +
	DOCK		8		Vol-		Vol -
	TV		9		Menu		Menu
	Game		Guide		Return		Back
	SAT/CBL		0		CH Level		Dual
	V.AUX		Pre Ch		Surround		3D
	Band		Red		Up		Up
	Mode		Green		Down		Down
	Shift		Yellow		Left		Left





Original	Replacement	Original	Replacement
	Right		Right
	Enter		Ok
	Night		Eject
	Restorer		D. Menu
	Tone		Info
	Test		Options
	Dimmer		List
	< Surround		Shift + Left
	> Surround		Shift + Right
	up Tuning		Shift + Up
	Down Tuning		Shift + Down
	Play Ipod		Play
	Pause Ipod		Pause
	Stop Ipod		Stop
	<< Ipod		<<
	>> Ipod		>>
	Repeat Ipod		Text
			Random Ipod
			I<< Ipod
			>>I Ipod
			Format

