






























































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	TV		TV/R
	Radio		Shift + TV/R
	Rec-Menu / Clock		AV
	Rec-Menu / Clock		Shift + Rec
	Rec-Menu / Clock		Options
	Title		Smart
	Audio		Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	EPG		Guide
	PIP		Format
	Assist		Media
	Text / Disc-M		Text
	Text / Disc-M		D. Menu
	Menu		Menu
	End		Exit
	Info		Info
	V+		Vol +
	V-		Vol -
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	Right		Right





Original	Replacement	Original	Replacement
 Left	 Left		
 OK	 Ok		
 Red / C-Set	 Red		
 Green / SV	 Green		
 Yellow / Zoom	 Yellow		
 Blue / Marker	 Blue		
 Play	 Play		
 <<	 <<		
 >>	 >>		
 Rec	 Rec		
 Pause	 Pause		
 Stop	 Stop		

