



Original	Replacement	Original	Replacement
 Power	 Power	 Exit	 Exit
 [=i]/Info	 Info	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 Enter	 Ok
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 Mute	 Mute
 0	 0	 List	 List
 [=?]/Source	 AV	 Sleep	 Sleep
 O)/II/Audio	 Dual	 EPG	 Guide
 Menu	 Menu	 ♥	 Pre Ch
 [=♦]/[+]	 3D	 Red	 Red
 Recall	 Back	 Green	 Green





	Original	Replacement	Original	Replacement
	Yellow			Yellow
	Blue			Blue
	<<			<<
	>>			>>
	<<			<<
	>>			>>
	Play			Play
	Pause			Pause
	Stop			Stop
	Rec			Rec
	[≡]			Text
	[≡+]/Still			Format
	[≡o]/Subtitle			Subt
	Radio			TV/R
	[≡x]			Options
	DMP			Smart
	Index			Media

