








































































| Original | Replacement | Original | Replacement |
|---|---|--|--|
|  Standby/On |  Power |  I<< |  I<< |
|  1 |  1 |  Play |  Play |
|  2 |  2 |  >>I |  >>I |
|  3 |  3 |  Time/Info |  AV |
|  4 |  4 |  Menu |  Menu |
|  5 |  5 |  Folder/Preset Up |  Up |
|  6 |  6 |  Folder/Preset |  Down |
|  7 |  7 |  Right File/A-E |  Right |
|  8 |  8 |  Left File/A-E |  Left |
|  9 |  9 |  Enter |  Ok |
|  0 |  0 |  Input Up |  Ch + |
|  Dimmer |  Media |  Input Down |  Ch - |
|  Prog |  Shift + Sleep |  Display |  Info |
|  Repeat/Freq/Text |  Text |  Sleep |  Sleep |
|  Pause |  Pause |  Vol+ |  Vol + |
|  Stop/PTY Seek |  Stop |  Vol- |  Vol - |
|  Random/PTY Seek Start |  Smart |  CD |  Yellow |





| | Original | Replacement | | Original | Replacement |
|---|----------|---|-------|----------|-------------|
|  | Tuner |  | TV/R | | |
|  | Band |  | Green | | |
|  | Tape/MD |  | Subt | | |
|  | AUX/TV |  | Red | | |
|  | Dock |  | Blue | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

