



































































Original	Replacement
 Standby	 Power
 Off	 Shift + Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 _/---/Del	 GUIDE
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Content (Home)	 Smart

Original	Replacement
 Source	 AV
 CH+	 Ch +
 CH-	 Ch -
 Magicinfo/Lite /S	 Media
 Menu	 Menu
 Blank	 Pre Ch
 Tools	 Options
 Info	 Info
 Return	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Red/PC	 Red
 Green/DVI	 Green





Original		Replacement		Original	Replacement
	Yellow/HDMI		Yellow		
	Blue/DP		Blue		
	Magicinfo		TV/R		
	3D		3D		
	Lock		Eject		
	Stop		Stop		
	<</ <<		<<		
	Play		Play		
	Pause		Pause		
	>>/>>		>>		

