































































Original		Replacement		Original		Replacement	
	Continue		Media		Disc 3		Yellow
	Shuffle		TV/R		Disc 4		Blue
	Program		Sleep		Disc 5		Smart
	1		1		Disc Skip		Back
	2		2		Play		Play
	3		3		Pause		Pause
	4		4		Stop		Stop
	5		5		I<< AMS		I<<
	6		6		AMS >>I		>>I
	7		7		<<		<<
	8		8		>>		>>
	9		9		M.Scan		Pre Ch
	10		0		Fader		Mute
	>10		Guide				
	Clear		Exit				
	Disc 1		Red				
	Disc 2		Green				

