



Original		Replacement		Original		Replacement	
	Power		Power		Recall		Back
	Mute		Mute		Sleep		Sleep
	Input		AV		Menu		Menu
	Aspect		Format		Tv/Radio		TV/R
	Nicam		3D		Display		Info
	P.Mode		Shift + Format		Exit		Exit
	S.Mode		Shift + Dual		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		OK		Ok
	5		5		CH+		Ch +
	6		6		CH-		Ch -
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		FAV		Pre Ch
	0		0		FAV+		Shift + Ch +





Original		Replacement		Original		Replacement	
	FAV-		Shift + Ch -		Yellow		Yellow
	EPG		Guide		Blue		Blue
	Text		Text				
	Hold		Options				
	Lang		Dual				
	Subtitle		Subt				
	Index/<<<		<<<				
	Size/>>>		>>>				
	Reveal/l<<<		l<<<				
	Subpage/>>>		>>>				
	Rec		Rec				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Media		Media				
	Red		Red				
	Green		Green				

