



Original	Replacement	Original	Replacement
 Power	 Power	 Pause	 Pause
 Mute	 Mute	 Menu	 Menu
 1	 1	 Exit	 Exit
 2	 2	 Digest	 Options
 3	 3	 FAV	 Pre Ch
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Scan	 Smart
 0	 0	 Edit	 3D
 Tv/Radio	 TV/R	 EPG	 Guide
 Recall	 Back	 Red	 Red
 i	 Info	 Green	 Green
 L/R	 Media	 Yellow	 Yellow
 Play	 Play	 Blue	 Blue



