



Original	Replacement	Original	Replacement
 Standby	 Power	 Green/Smart	 Green
 1	 1	 Yellow/Lock	 Yellow
 2	 2	 Blue/Sleep	 Blue
 3	 3	 Menu	 Menu
 4	 4	 Teletext	 Text
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 P<P	 Pre Ch	 OK	 Ok
 Clear	 Exit	 Vol+	 Vol +
 Mute	 Mute	 Vol-	 Vol -
 Record	 Rec	 >I/Index	 Format
 Timer	 AV	 >I</Still	 3D
 Red/Select	 Red	 <<	 <<



