















































| Original | Replacement | Original | Replacement |
|---------------|-----------------------------|------------|-----------------------|
| Guide | Guide / EPG / -/-- | Play | Play / Slow |
| Power | Power | Pause | Pause / Step / Freeze |
| Eject | Eject / Surround | << | << / Tune- |
| Tv/Radio | TV/Radio / | >> | >> / Tune+ |
| Red/Goto | Red / Netflix / Search | D.Setup | Setup / OPT / |
| Green/Angle | Green / APP / Repeat | Rec | Rec / Rec Mode |
| Yellow/Repeat | Yellow / YouTube / Repeat | Stop | Stop / Hold |
| Blue/A-B | Blue / Prime Video / Random | I<< | I<< / Preset- |
| FAV | Fav / Marker / PC | >>I/Index | >>I / Preset+ |
| Text | Text / Goto | Menu | Menu / Home |
| Freeze/Hold | Shift + Pause / Step / | Lang/Audio | Audio / Lang I/II |
| D.Menu | D.Menu / Top | Up | Up |
| Subtitle | Subtitle / EQ | Left | Left |
| Zoom/Size | Zoom / Size | OK | OK |
| Aspect | Shift + Picture / Format | Right | Right |
| Subpage | Info / Angle | Sleep | Sleep / Timer |
| Media | Shift + Display / Media | Down | Down |





| Original | Replacement |
|--|--|
|  Title/Exit |  Exit / Cancel / Clear |
|  Vol+ |  Vol+ |
|  Mute |  Mute / Dimmer |
|  CH+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  Display |  Display / Media |
|  CH- |  CH- / Page- |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  -/-- |  Shift + Guide / EPG / -/-- |

| Original | Replacement |
|--|--|
|  0 |  0 |
|  Back |  Back / Return |
|  Source |  AV / Input / RDS |
|  P.Mode |  Picture / Format |
|  S.Mode |  Sound / Title |

