







































































	Original	Replacement		Original	Replacement
	Power		Power		Tuner
	Sleep		Sleep		TV / AUX
	DIM		3D		Display
	Open / Close		Eject		EQ
	1		1		Surround
	2		2		Language
	3		3		Audio
	4		4		Select
	5		5		Go To
	6		6		Volume -
	7		7		Volume +
	8		8		Title
	9		9		Menu / PBC
	0		0		Return
	+10		Guide		Setup
	Mute		Mute		Up
	DVD		AV		Right
					Shift + TV/R
					TV/R
					Info
					Media
					Shift + Dual
					Dual
					Shift + Subt
					Smart
					Shift + Smart
					Vol -
					Vol +
					List
					Menu
					Back
					Options
					Up
					Right



