






































Original	Replacement	Original	Replacement
	Power		Power
	Subtitle		Subt
	APP/*		Shift + Media
	[]/Ratio		3D
	Input		AV
	Tv/Rad		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Q.View		D. Menu
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	FAV		Pre Ch
	Guide		Guide
	P+		Ch +
	P-		Ch -
	Info		Info
	Smart		Smart
	My APPS		Media
	Back		Back
	Settings		Options
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right





Original		Replacement		Original		Replacement	
	Left		Left				
	OK		Ok				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text		Text				
	T.OPT	 + 	Shift + Options				
	Q.Menu		Menu				
	Sleep		Sleep				
	AD		Dual				
	Stop		Stop				
	Play		Play				
	Pause		Pause				
	<<		<<				
	>>		>>				
	Rec / *		Rec				

