






































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	[]		TV/R
	Sound		Dual
	*		Options
	Source		AV
	[X]		Format
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]/[?]		Info
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡]/Text		Text
	-/--/Recall		Pre Ch
	Guide		Guide
	Up		Up
	OK		Ok
	Down		Down
	Right		Right
	Left		Left
	Prog+		Ch +
	Prog-		Ch -
	Vol+		Vol +
	Vol-		Vol -



