







































































	Original	Replacement		Original	Replacement
	 Power	 Power		 0	 0
	 Sleep	 Sleep		 PSM	 Format
	 Display	 Info		 SSM	 Shift + Dual
	 Mute	 Mute		 OK	 Ok
	 NICAM	 Dual		 Q.View	 D. Menu
	 PC	 AV		 Up / P +	 Up
	 Auto AD	 Shift + Subt		 Up / P +	 Ch +
	 TV / AV	 TV/R		 Down / P -	 Down
	 1	 1		 Down / P -	 Ch -
	 2	 2		 Right / V +	 Vol +
	 3	 3		 Right / V +	 Right
	 4	 4		 Left / V -	 Vol -
	 5	 5		 Left / V -	 Left
	 6	 6		 Menu	 Menu
	 7	 7		 Index	 Smart
	 8	 8		 Subtitle	 Subt
	 9	 9		 Mix	 Media





Original	Replacement
Text	Text
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Time	Shift + AV
Hold	Pause
Size	Eject
Reveal	3D

Original	Replacement

