





	Original	Replacement		Original	Replacement
	Power		Power		<< Rev
	Open / Close		Eject		>> Fwd
	Language		Dual		I<< Prev
	Angle		Format		>>I Next
	Subtitle		Subt		Menu
	Prog		Sleep		Title
	1		1		Up
	2		2		Right
	3		3		Down
	4		4		Left
	5		5		Enter
	6		6		Time
	7		7		Setup
	8		8		PBC
	9		9		Vol +
	0/10		0		Vol -
	10+		Guide		Zoom
					Shift + Guide
					Vol +
					Vol -
					Shift + Eject





Original	Replacement	Original	Replacement
 Return	 Back		
 A-B	 D. Menu		
 Repeat	 Text		
 P-Scan	 Media		
 Step	 Shift + Pause		
 Slow	 Shift + Play		
 N/P	 Red		
 L/R	 Green		
 Mute	 Mute		
 Display	 Info		
 Play/Pause	 Play		
 Stop	 Stop		
 Play/Pause	 Pause		
 Default	 Smart		

