

















Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide
 TV / AV	 AV
 Green / Timer	 Green
 Green / Timer	 Shift + AV
 Blue / QV	 Blue

Original	Replacement
 Red / Info	 Red
 Red / Info	 Info
 V-PP	 Options
 Yellow / V-PP	 Yellow
 Zoom	 Eject
 A-PP	 Dual
 Up / P+	 Up
 Up / P+	 Ch +
 Menu	 Ok
 Down / P-	 Down
 Down / P-	 Ch -
 Right / V+	 Right
 Right / V+	 Vol +
 Left / V-	 Left
 Left / V-	 Vol -
 Menu	 Menu
 Reveal	 Smart





Original	Replacement	Original	Replacement
SIZE 	Size	PICTURE FORMAT 	Format
MIX 	Mix	SHIFT + REPEAT TEXT 	Shift + Text
TV/TXT 	TV / TXT	REPEAT TEXT 	Text
CANCEL 	Cancel	RETURN BACK 	Back
SUBCODE 	Subcode	AD SUBT 	Subt
INDEX 	Index	APP MEDIA 	Media
STOP 	Stop		Stop

Original	Replacement

