



Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Mute		Mute		9		9
	Audio		Dual		0		0
	TV / STB		Shift + TV/R		PGUP		Vol +
	TV / R		TV/R		PGDN		Vol -
	Sleep		Sleep		SAT		Shift + AV
	SUB		Subt		FAV +		Ch +
	TXT		Text		FAV -		Ch -
	P / N		Shift + 1		EPG		Guide
	Recall		Pre Ch		Fav		Shift + Pre Ch
	1		1		Up		Up
	2		2		Right		Right
	3		3		Down		Down
	4		4		Left		Left
	5		5		OK		Ok
	6		6		Menu		Menu
	7		7		Exit		Exit





Original	Replacement	Original	Replacement
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Pause		Pause
	Zoom		Eject
	Edit		Format
	Info		Info
	USB		AV
	MP3		Media
	JPEG		Smart
	PVR List		List
	A - B		Back
	T.S.		Shift + 2
	Goto		Options
	Stop		Stop
	Rec		Rec
	<<		<<
	>>		>>
	Play / Pause		Play
	> <		Shift + Pause
	<<		<<
	>>		>>

