





















| Original | Replacement |
|--|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Back |  Back |
|  Fav |  Pre Ch |
|  Menu |  Menu |
|  Exit |  Exit |
|  EPG |  Guide |

| Original | Replacement |
|---|--|
|  i |  Info |
|  Up |  Up |
|  Right |  Right |
|  Down |  Down |
|  Left |  Left |
|  OK / List |  Ok |
|  OK / List |  List |
|  V + |  Vol + |
|  V - |  Vol - |
|  TV / R |  TV/R |
|  SAT |  AV |
|  P + |  Ch + |
|  P - |  Ch - |
|  Red / F1 |  Red |
|  Green / F2 |  Green |
|  Yellow / F3 |  Yellow |
|  Blue / F4 |  Blue |





| Original | Replacement | Original | Replacement |
|---|---|----------|-------------|
|  Audio |  Dual | | |
|  Subtitle |  Subt | | |
|  Text |  Text | | |
|  Pause |  Pause | | |
|  UHF |  Format | | |
|  Parab |  3D | | |
|  M1 |  Shift + 1 | | |
|  N / P |  Options | | |
|  Timer / Sleep |  Shift + Power | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

