







































































| Original | Replacement | Original | Replacement |
|--|---|---|---|
|  Power |  Power |  7 |  7 |
|  Mute |  Mute / Dimmer |  8 |  8 |
|  Audio |  Audio / Lang I/II |  9 |  9 |
|  TV / STB |  AV / Input / RDS |  0 |  0 |
|  TV / R |  TV/Radio / |  SAT |  Shift + 0 |
|  Sleep |  Sleep / Timer |  EPG |  Guide / EPG / -/- |
|  SUB |  Subtitle / EQ |  Fav |  Fav / Marker / PC |
|  TXT |  Text / Goto |  PGUP |  CH+ / Page+ |
|  Multi |  Display / Media |  PGDN |  CH- / Page- |
|  P / N |  Picture / Format |  Up |  Up |
|  Recall |  Back / Return |  Right |  Right |
|  1 |  1 |  FAV + |  Vol+ |
|  2 |  2 |  FAV - |  Vol- |
|  3 |  3 |  Down |  Down |
|  4 |  4 |  Left |  Left |
|  5 |  5 |  OK |  OK |
|  6 |  6 |  Menu |  Menu / Home |





| Original | Replacement |
|---|--|
|  |  Exit / Cancel / Clear |
|  |  Red / Netflix / Search |
|  |  Green / APP / Repeat |
|  |  Yellow / YouTube / Repeat |
|  |  Blue / Prime Video / Random |
|  |  Pause / Step / Freeze |
|  |  Zoom / Size |
|  |  D.Menu / Top |
|  |  Info / Angle |
|  |  Shift + 8 |
|  |  Shift + Yellow / YouTube / |
|  |  Shift + Text / |
|  |  Shift + 1 |
|  |  Shift + 2 |
|  |  Eject / Surround |
|  |  Stop / Hold |
|  |  Rec / Rec Mode |

| Original | Replacement |
|---|---|
|  |  Sound / Title |
|  |  << / Tune- |
|  |  >> / Tune+ |
|  |  Smart / List |
|  |  Play / Slow |
|  |  I<< / Preset- |
|  |  Setup / OPT / |
|  |  >>I / Preset+ |

