







































































| Original | Replacement | Original | Replacement |
|---|--------------|---|-------------|
|  | Power |  | Power |
|  | Ambilight |  | Options |
|  | * |  | Menu |
|  | Colors |  | Info |
|  | Sources/Pair |  | AV |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | OK |  | Ok |
|  | ← |  | Back |
|  | Home |  | Smart |
|  | + |  | Pre Ch |
|  | << |  | << |
|  | Play |  | Play |
|  | >> |  | >> |
|  | Stop |  | Stop |
|  | Pause |  | Pause |
|  | Rec |  | Rec |
|  | Red |  | Red |
|  | Green |  | Green |
|  | Yellow |  | Yellow |
|  | Blue |  | Blue |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | Netflix |  | Media |
|  | Windows |  | D. Menu |
|  | CH+ |  | Ch + |
|  | CH- |  | Ch - |
|  | Rakuten Tv |  | TV/R |
|  | Exit TV |  | Exit |
|  | 1 |  | 1 |
|  | 2 |  | 2 |



