



Original	Replacement
	
Power	Power
	
1	1
	
2	2
	
3	3
	
4	4
	
5	5
	
6	6
	
7	7
	
8	8
	
9	9
	
0	0
	
Lang	Dual
	
TXT	Text
	
Vol+	Vol +
	
Vol-	Vol -
	
Mute	Mute
	
Source	AV

Original	Replacement
	
P+	Ch +
	
P-	Ch -
	
Guide	Guide
	
Menu	Menu
	
i	Info
	
Back	Back
	
Exit	Exit
	
Up	Up
	
Down	Down
	
Right	Right
	
Left	Left
	
OK	Ok
	
Netflix	Media
	
F Play	TV/R
	
You Tube	Smart
	
Prime Video	Options
	
Red	Red



[illegible]