




















Original	Replacement
	Power
	Auto
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	-/--
	Recall
	Vol +
	Vol -

Original	Replacement
	Aspect
	Nicam
	Display
	CH +
	CH -
	Up
	Right
	Down
	Left
	Enter
	Menu
	Exit
	Input
	P.Mode
	S.Mode
	Sleep
	Text



