



| Original | Replacement | Original | Replacement |
|--|--|---|--|
|  Power |  Power |  0 |  0 |
|  Mute |  Mute |  Menu |  Menu |
|  FAV |  Pre Ch |  Exit |  Exit |
|  Subtitle |  Subt |  EPG |  Guide |
|  Info |  Info |  Goto |  Shift + Guide |
|  TTX |  Text |  Up |  Up |
|  Recall |  Back |  Down |  Down |
|  List |  List |  Right |  Right |
|  1 |  1 |  Left |  Left |
|  2 |  2 |  OK |  Ok |
|  3 |  3 |  Vol + |  Vol + |
|  4 |  4 |  Vol - |  Vol - |
|  5 |  5 |  Pg Up |  Shift + Up |
|  6 |  6 |  PG Dn |  Shift + Down |
|  7 |  7 |  CH + |  Ch + |
|  8 |  8 |  CH - |  Ch - |
|  9 |  9 |  >> |  >> |





| Original | Replacement | Original | Replacement |
|---|--|----------|-------------|
|  << |  << | | |
|  >> |  >> | | |
|  << |  << | | |
|  Play |  Play | | |
|  Pause |  Pause | | |
|  Stop |  Stop | | |
|  Rec |  Rec | | |
|  Lang |  Dual | | |
|  Timeshift |  Smart | | |
|  Tv/Radio |  TV/R | | |
|  Repeat |  Shift + Text | | |
|  Red / Zoom |  Red | | |
|  Green / Aspect |  Green | | |
|  Yellow / V-Format |  Yellow | | |
|  Blue / Timer |  Blue | | |
| | | | |
| | | | |

